




Coast Phase

Delay Charge allows model to coast and reduce speed before deploying the recovery device.

Recovery Deployment



Ejection Charge pressurizes the inside of the rocket body, blowing the Nose Cone off and pushing out the recovery device.

Descent Phase


Recovery Device slows model descent...

Boost Phase


Thrust produced by burning propellant propels model to great speed and altitude



Ignition



Model rocket is electrically ignited



MODEL ROCKET IN FLIGHT

Landing!



...for a soft landing, ready to be prepared for another flight!

